

## ERREU08 - Error message in the event of interpenetration

---

### Summary:

This test which do not comprise that only one modeling tests the emission of an error message when an interpenetration is detected and that one does not solve the contact.

This documentation is voluntarily brief.